

Value	Name	Summary	Conformance
3	Lockout3	Level 3 reduced functionality	M
4	Lockout4	Level 4 reduced functionality	M
5	Lockout5	Least functionality available to the user	M

The interpretation of the various levels is device-dependent.

4.5.5.3. ScheduleProgrammingVisibilityEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	ScheduleProgrammingPermitted	Local schedule programming functionality is enabled at the thermostat	M
1	ScheduleProgrammingDenied	Local schedule programming functionality is disabled at the thermostat	M

4.5.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	TemperatureDisplayMode	TemperatureDisplayModeEnum	all			RW VO	M
0x0001	KeypadLockout	KeypadLockoutEnum	all			RW VM	M
0x0002	ScheduleProgrammingVisibility	ScheduleProgrammingVisibilityEnum	all		ScheduleProgrammingPermitted	RW VM	O

4.5.6.1. TemperatureDisplayMode Attribute

This attribute SHALL indicate the units of the temperature displayed on the thermostat screen.